User Manual

Control Center
NFC-Connect
Professional Setup Manager

Legal notice

Manufacturer:	**JK-Products GmbH**
	Rottbitzer Straße 69
	53604 Bad Honnef (Rottbitze)
	GERMANY
	Phone: +49 (0) 22 24 / 818-140
	Fax: +49 (0) 22 24 / 818-166
Importer:	**JK-Products and Services, Inc.**
	411 West Washington Avenue
	Suite B
	Jonesboro, Arkansas 72401
	Phone: 800-643-0086
	Fax: 870-935-3618
Customer Service / Technical Service (Spare part orders for components):	**JK Products & Services, Inc. / JK-Global Service**
	411 West Washington Avenue
	Suite B
	Jonesboro, Arkansas 72401
	Phone: 800-445-0624 (toll-free)
	Fax: 870-935-9046
	e-mail: support@jkamerica.com
	http://support.jkamerica.com
Lamps and consumable parts:	**JK-Light**
	411 West Washington Avenue
	Suite B
	Jonesboro, Arkansas 72401
	Phone: 877-786-5267
	Fax: 870-268-1202
	http://www.jk-light.com

DANGER!

Failure to observe these operating instructions:
- may result in serious injury and death,
- can result in damage to the device and to the environment.
– Read these instructions carefully before putting this tanning device into operation.
– Please observe the instructions and the code of conduct required to operate the device safely.
– Make the operating instructions and additional information from the manufacturer available to the personnel at their workplace.

Copyright

The copyright remains with JK-Holding GmbH.

The contents may not be partially or completely duplicated, distributed or utilized for competition purposes without authorization or disclosed to other parties. The right to make technical changes in regard to the figures and information contained in these operating instructions is reserved!

Table of contents

We continuously work on improving our products in order to be in line with your requirements.
Please visit our website and download the latest user manual.

http://support.jkamerica.com

1   Control

## 1.1   User safety information

DANGER!

⚠️ **Danger of hearing damage!**

Using earphones or headphones at high volume can result in permanent hearing damage.

– Do not set the volume too high.

Observe the warning notices in the operating instructions for the device, in particular the contraindications.

1.2   Control Center overview

14876 / 1

1. NFC point
2. OK button (not always visible)
3. Navigation unit
4. Display

Sun Angel devices possess additional buttons,

1.2.1   Navigation

14820 / 1

OK   Confirm selection.
This button's availability is displayed in the Control Center, depending on the function that has been selected.

◀ ▶   Select device function

➕ ➖   Functions or settings can be activated, deactivated or changed.

Prestige- and Inspiration serie:

NFC point

Data exchange via contactless near-field communication - individual settings can be stored on a chipcard and loaded during the next session.

1.3   Operating Panel overview Sunrise (Model-No.: JK 158/48-0 and JK 158/48-0 VS)

18392 / 0

1.   Display – Functions ...
2.   Feature selection
3.   OK button (not always visible)
4.   Bluetooth® pictogram

1.4   User settings overview

All of the device's available functions can be pre-set in the Control Center. The fine adjustment is carried out during the application using the control panel on the inside of the device.

The user settings can be saved to a special customer card so that they do not have to be set again during the next application.

The stored data can be transferred to other devices with similar setting options.

The START/STOP button is only available on the control panel on the inside of the device.

Function	Pictogram selection / key sequence	Description / display
Body fan	HIGH ▶AUTO LOW	Pre-select low or high cooling or set to automatic.
Face fan	HIGH ▶AUTO LOW	Pre-select low or high cooling or set to automatic.
Facial tanner	▶MAX MED OFF	Select maximum or medium power or switch off.
Climatronic/ Air conditioning	WARM ▶AUTO COOL	Pre-select low or high temperature or set to automatic.
AROMA	▶ON OFF	Switch AROMA on or off
AQUA SYSTEM	▶BOTH BODY FACE OFF	Switch the AQUA SYSTEM body and head nozzles on or off together or individually
Shoulder tanner	▶ON OFF	Switch the shoulder tanner on or off
Voice Guide	▶ON OFF	Switch the Voice Guide on or off
Volume	HIGH ▶AUTO LOW	Basic volume setting: Loud, quiet or automatic.
Audio system	▶AUX SALON SOLARIUM OFF AUTO	Select the audio system or switch off

Function	Pictogram selection / key sequence	Description / display
Prestige- and Inspiration serie:		
Transfer data	TO SAVE HOLD DATA CARRIER CLOSE TO THE TRANSMITTER .	Hold the customer card close to the NFC point (maximum distance 3 cm) to transfer the settings
Data transfer	DATA TRANSFERRED	
Welcome	WELCOME	Welcome text in standby mode

1.4.1 Prestige- and Inspiration serie: Saving the settings to a chipcard (tag)

TO SAVE HOLD
DATA CARRIER
CLOSE TO THE
 TRANSMITTER .

After setting all of the functions, the next time ▶ is pressed the display shows the message *To save hold data carrier close to the transmitter.*

– Hold the customer card close to the NFC point.
   The settings are automatically saved to the card.

NFC status

The data transfer is indicated by colours.

 The NFC point flashes pulsating:
Ready for use / Standby

During the fan run-on, the NFC point flashes in transmit mode:
The settings can be transferred to a data carrier.

 The centre point of the NFC point is green:
Settings have been successfully transferred from the data carrier to the solarium.

 The centre point of the NFC point is blue:
Settings have been successfully transferred to the data carrier.

 The centre point of the NFC point is orange:
a) Transmission error

– Hold the card in front of the point again and wait a little longer.

b) The data carrier is empty.

After tanning, the settings can be saved to the data carrier.

## 1.4.2 Prestige- and Inspiration serie: Loading settings from a chipcard

The settings saved on the customer card or service card (PROFESSIONAL SET-UP CARD, LED LIGHT SHOW & ECO TECH ENERGY SAVING) can be read by all devices equipped with Control Center and the corresponding setting options. With one restriction: The studio operator has the option of providing issued cards with a unique identification so that they can only be used in his studios.

Function	Action	Description / display
Read data		Hold the customer card close to the NFC point (maximum distance 3 cm).
DATA RECEIVED		The device shows whether the data transfer has succeeded or failed.
NO DATA		The customer card does not contain any data or the card is invalid (incorrect NFC card group)
TRANSFER LIGHTING		Message that data are transferred at the moment.
CURRENTLY NOT POSSIBLE		The device is not in Standby mode.

## 1.5 Additional Beauty Angel SUN 700 and Balance 770 SELECT functions

The Voice Guide on Beauty Angel devices will guide you through the individual steps for the use of the sensor.

17349 / 0

1. START/STOP button
2. OK button
3. Navigation unit
4. Display – Functions …

1.5.1 Selection of the application

Before the session begins, the desired application type must be selected. There are 3 possible selections:


17350 / 0

- PURE BEAUTY: Only the Beauty Light lamps are switched on. The sensor is not used for this application.
- BEAUTY & SUN: Beauty Light lamps and UV lamps are switched on. The proportion of UV radiation is up to 30 %. The sensor is used for this application.
- SUN & BEAUTY: Beauty Light lamps and UV lamps are switched on. The proportion of the UV radiation is higher than the proportion of the Beauty Light lamps, depending on the skin type and base tan. The sensor is used for this application.
– Press the button for the desired type of application.

If the sensor is not used the device will be operated using the legally prescribed minimum power of the UV lamps.

1.6   Additional Sun Angel functions

Sun Angel tanning units display the individual steps for the use of the sensor in the Control Center. The application type selection is now part of the expanded controls of the Control Center.

14811 / 1

1. NFC point
2. OK button (not always visible)
3. Navigation unit
4. Display
5. Application type: STYLING SUNSHINE
6. Application type: ESSENTIAL SUNSHINE

1.6.1   Selecting the application type

14920 / 0

Before the session begins, the desired application type must be selected. There are 2 possible selections:

• ESSENTIAL SUNSHINE: Only the UV-B lamps are switched on.

• STYLING SUNSHINE: UV-A lamps and UV-B lamps are switched on.

– Press the button for the desired application type.

1.6.2 Measurement (automatic mode)

If the sensor is not used the device will be operated using the legally pre-scribed minimum power of the UV lamps (see the function description in the device's operating instructions). The device's operating instructions also contain a detailed description of the sensor display.

NOTICE:
The blood flow of the skin has an effect on the measurement result. As a result, your physical condition on the day, sporting activities or extreme ambient temperatures can result in different measurement results.

14340 / 0

14341 / 0

Display	Description
NFC-MEDIUM ▶ ◀ PROGRAM	Sun Angel devices are also capable of reading a customer card or the application type can be selected manually as described above.
TAKE SENSOR FROM ITS HOLDER	After selecting the application type the sensor must be removed from the station in automatic mode.
1. MEASUREMENT FOREHEAD	Hold the sensor to your forehead (not in the centre), press and wait for the signal tone. The measurement must be repeated if a corresponding message is displayed.
2. MEASUREMENT BODY	Place the sensor on the lightest place on the body, for example on the inside of the upper arm, and press. Wait for the signal tone. The measurement must be repeated if a corresponding message is displayed.
SENSOR RETURN TO STATION	
MEASUREMENT ▷ OK COMFORT SELECTION ▶ OR ENTER THE TANNING BED	Now you can pre-set all of the device functions, see page 6 onward. These settings can be saved to a customer card. **Note:** The measurement results are not saved to the customer card.
MEASUREMENT ▷ OK COMFORT ▷ OK TANNING BED READY TO OPERATE	The application can start.

Measurement failed 4x

SENSOR
MEASUREMENT
INVALID

If a measurement fails 4x then the device will operate at the minimum legally required power setting.

Start: see the operating instructions for the device.

2 Professional Setup Manager

In the Professional Setup Manager operating states can be called up and presettings entered.

2.1 General instructions

NOTICE:
- Presetting mode can only be called up when tanning is not taking place.
- 8 seconds after the last button was pressed, the device changes automatically into standby mode and the currently set values are saved.

2.1.1 Opening the Professional Setup Manager (Presetting mode)

– To open the Professional Setup Manager press ⊖ for approximately 3 seconds.

In delivery condition you immediately access the presettings.

If a master code has been set:
– Enter the master code.

Prestige- and Inspiration serie:

Alternatively, you can call up the presettings with the PROFESSIONAL SET - UP CARD:
– Hold the PROFESSIONAL SET - UP CARD close to the NFC point.

Control

OK Confirm selection.
This button's availability is displayed in the multi-function panel, depending on the function that has been selected.

◀ ▶ Select device function

➕ ➖ Functions or settings can be activated, deactivated or changed.

Prestige- and Inspiration serie:

NFC CONNECT

Data exchange via contactless near-field communication - individual settings can be stored on a chipcard and/or transferred to the device.

2.1.2 Master code

The master code allows you to access all of the presettings.
If you know the current master code, you can specify a new code at any time.
If you have forgotten the code, please contact customer service.

Code upon delivery (factory default)
Master code: 0001 (no entry necessary)

> **NOTICE:**
> We recommend that you set a new master code when starting up the device for the first time in order to prevent unauthorized access to the presetting mode.
> Please make a note of the code for customer service.

Changing the code
– In the Professional Setup Manager please select the '01 Control' menu.
– Continue pressing the right arrow until the master code display appears.

Display:	Change master code:
0001 MASTER-CODE	Change the current digits using + or -.
	Use the arrow keys to select the next digit.
	Press the right arrow once the desired code has been set. The set code is saved.

2.1.3 Viewing and changing presettings

Display:	Action:
PROFESSIONAL SETUP ▸ MANAGER	Use the arrow keys to access the previous or following main menu.
	In some cases, a selection must be confirmed with OK. The OK button is only visible if it is required in the current situation.
⌂OK ◆ **0001** MASTER-CODE ±	Changing values: Press + and - to change a digit, use the arrow keys to change between digits.
⌂OK ◆ ☐ BODY VENTILATION ☐ FACIAL VENTILATION ☐ FACIAL TANNER ☐ AIR CONDITION CONFIGURE MENU ±	Example: Highlight a selection field. Use the arrow keys to move between the sub-items. Use the plus or minus button to select or deselect items.

Changing a presetting

NOTICE:

To scroll through the pages or change any settings, do not hold down the button (scroll). Instead, touch the button several times sequentially:

The value changes when the button is pressed

- up to 5 times in individual steps,
- between 5 and 10 times in steps of five,
- and then in steps of 10.

Resetting to the delivery condition

Display	Description
◂ **OPERATION** ▸ OK	Select the 'Operation' menu and open with OK.
⌂OK ◆ ⊞ **ACTIVATE** RESET	Press and hold the START/STOP button until 'Activate', 'Reset' appears. Press the + button.
⌂OK ◆ **TANNING BED RESET** RESET	All presettings are reset to their factory default values.

2.1.4 Prestige- and Inspiration serie: Chipcards

The settings in the presetting menus can be saved to chipcards. Pre-configured chipcards are available on which only specific settings can be saved. This allows for quick and convenient data transfer to other devices.

PROFESSIONAL SET-UP CARD: All settings are saved on this card; it also serves as a backup.

LED LIGHT SHOW: The accent lighting settings are saved on this card.

ECO TECH ENERGY SAVING: The settings from the EcoTech menu are saved on this card.

2.2　　　Presettings overview

| Default setting	Description
Menu 01 CONTROL	
CONTROL OK	Multi-function panel settings for the user: Key tones, display settings, selection of the functions displayed on the user menu.
10 BRIGHTNESS DISPLAY ±	Display brightness: 0-10
40 CONTRAST DISPLAY ±	Display contrast: 30-50
2 KEY SOUNDS ±	Tone selection: 1 (beep) / 2 (click) / 3 (laser)
25 VOLUME KEY SOUNDS ±	Key tone volume: 0-25
ACTIVATED TIME ±	Time: on or off
0001 MASTER-CODE ±	Change the master code.
0001 NFC-CARD-GROUP ±	*Prestige- and Inspiration serie:* The 4-digit alphanumeric PIN which is written to the cards as identification. This enables studios and operators to define card groups.
BODY VENTILATION FACIAL VENTILATION FACIAL TANNER AIR CONDITION CONFIGURE MENU ±	Selection of the functions displayed in the user menu (additional functions are displayed using the right arrow).
WELCOME	Welcome text in standby mode. Maximum text length: 3 lines each with 13 characters

Default setting	Description
Menu 02 LIGHTING	
LIGHTING ◀ ▶ OK	Set the duration and colours of the accent lighting
ERGOLINE — LED COLOR PROGRAM ±	Select a preset or custom designed programme: Ergoline 0-999 (no customized colour selection) Sun Angel 1000-1999 (no customized colour selection) Not assigned 2000-2999 (no customized colour selection) Static 3000 (with customized colour selection) Own 3001 (with customized colour selection) Card 4000-4999 (no customized colour selection)
005 — COLOR SELECTION ±	01-90 Force static
100% — BRIGHTNESS ±	LED brightness: 100% / 80% / 60%
PERMANENT — RUNTIME ±	Permanent or time in minutes
ACTIVATED — DAILY TIMER ±	Switch day timer on or off
SUNDAY ▼ 09:15 - 18:00 — DAILY TIMER ±	The time from when to when the accent lighting is switched on can be defined for each day of the week (Monday to Sunday).
Menu 03 ECO TECH	
◀ ECO TECH ▶ OK	This menu can be used to change the performance of individual components in order to optimize energy consumption.
ACTIVATED — ECO-MODE	Switch ECO mode on or off. The performance of individual components can be changed when ECO mode is activated.

Default setting	Description
OK **PERFORMANCE** UV-PERFORMANCE ±	PERFORMANCE/ECO When ECO mode is selected the lamp output is decreased slightly. Select PERFORMANCE to utilize the full lamp output.
OK **ACTIVATED** AIR-CONDITION ±	Switch air conditioning on or off.
OK **ACTIVATED** HEATING ±	Switch heating on or off.
OK **ACTIVATED** VENTILATION ±	Switch ventilation (head and body cooling) on or off.
OK **80%** LIGHTING ±	There are 3 settings for the accent lighting brightness: 100%, 80%, 60%

Menu 04 DEVICE INFORMATION

TANNING BED ◀ INFORMATION ▶ OK	Technical information about the device such as bus addresses, software version
OK MAINC 08 1500300 001.167 SENSO 90 1504446 000.025 EXTCN 94 1507517 000.029 DISPLY C8 1500621 000.054 DEVICE INFORMATION	Information for the customer service about the installed components.
OK FTFAN DC 1500433 001.005 AUDIO F2 1505335 000.003 ARDAQ F4 ..12282 002.000 CLIMA F6 ..12280 000.007 DEVICE INFORMATION	Information for the customer service about the installed components.
OK COPRO F8 1500467 003.001 ILLUMI FA 1507479 000.022 ILLUMI FA 1507517 000.029 ILLUMI FA 1507479 000.022 DEVICE INFORMATION	Information for the customer service about the installed components.
OK 00 1500000 000.000 00 1500000 000.000 00 1500000 000.000 00 1500000 000.000 DEVICE INFORMATION	Information for the customer service about the installed components.

Default setting	Description
⌂☐OK ◀▶ ENGLISCH **US** **1508023** **VERSION: 000.26** ▮DEVICE INFORMATION	Information for the customer service about the installed components.

Menu 05 HOURS OF OPERATION

HOURS OF ◀ **OPERATION** ▶ **OK**	The operating hours for all of the maintenance-relevant components can be called up and reset using this menu.
⌂☐OK ◀▶ **TOTAL** **0000:00:00** ▮HOURS OF OPERATION ±	Total device operating hours.
⌂☐OK ◀▶ **LOW PRESSURE** **0015:01:11** ▮HOURS OF OPERATION ±	Low-pressure lamp operating hours. Automatically reset when the lamp set and the corresponding chipcard are replaced.
⌂☐OK ◀▶ **LAMP TYPE A** **0015:01:11** ▮HOURS OF OPERATION ±	Type A low-pressure lamp operating hours (Only for devices with 2 types of lamps such as the Sun Angel). Automatically reset when the lamp set and the corresponding chipcard are placed.
⌂☐OK ◀▶ **LAMP TYPE B** **0015:01:11** ▮HOURS OF OPERATION ±	Type B low-pressure lamp operating hours (Only for devices with 2 types of lamps such as the Sun Angel). Automatically reset when the lamp set and the corresponding chipcard are placed.
⌂☐OK ◀▶ **LAMP TYPE C** **0000:00:00** ▮HOURS OF OPERATION ±	Type C low-pressure lamp operating hours (only for combi-devices with collagen lamps). Automatically reset when the lamp set and the corresponding chipcard are placed.
⌂☐OK ◀▶ **FACE** **0500:00:00** ▮HOURS OF OPERATION ±	Remaining operating hours for the high-pressure lamps in the facial tanner
⌂☐OK ◀▶ **SHOLDER** **0500:00:00** ▮HOURS OF OPERATION ±	Remaining operating hours for the high-pressure lamps in the shoulder tanner
⌂☐OK ◀▶ **FILTER** **0050:00:00** ▮HOURS OF OPERATION ±	Remaining operating hours for the filters in the canopy and front panel.

Default setting	Description
AIR CONDITION **0000:00:00** HOURS OF OPERATION ±	Operating hours of the air conditioning and the filter in the air conditioning.
AQUA MIST **0005:29:24** HOURS OF OPERATION ±	Operating hours of the Aqua Fresh function.

Menu 06 Time

TIME OK	Time and date settings
13:34:19 TIME ±	Set the time
MO 14.10.13 DATE ±	Set the date
ACTIVATED TIME ±	24 hour time display on or off.

Menu 07 AC / COOLING

AC AND COOLING OK	Threshold temperatures for switching the air conditioning and heating on and off
ACTIVATED AIR-CONDITION ±	Switch the air conditioning on or off
ACTIVATED HEATING ±	Switch the heating on or off

Default setting	Description
MAX TEMPERATURE **30°C** HEATING	Only for units with Climatronic: The maximum temperature which the user can set on the device.
MIN TEMPERATURE **18°C** HEATING	Only for units with Climatronic: The lowest temperature which the user can set on the device.
START TEMPERATURE **20°C** HEATING	The heating starts at the temperature specified here or at a lower intake air temperature.
TEMPERATURE LIMIT **15°C** AIR-CONDITION	Lower air conditioning temperature threshold
REFERENCE VALUE **20°C** ROOM TEMPERATURE	Room temperature setpoint (only for ventilation systems with warm air recovery)
ACTIVATED WARM AIR RECOVERY	Activate or deactivate the warm air recovery
CELSIUS TEMPERATURE DISPLAY	Changing between °Celsius and °Fahrenheit
03 MINUTES FAN RUN ON	Device fan warm-down time
ACTIVATED VENTILATION	Switch the ventilation on and off (when ECO MODE is activated)
ACTIVATED WINTER OPERATION	Switch winter mode on or off; this setting optimizes the device's energy consumption. OFF = summer mode: At room temperatures above 25°C the minimum temperature of the body cooling is increased by 5°C.

Default setting	Description
Menu 08 AROMA / AQUA SYSTEM	
AQUA MIST AND AROMA ◄ ► OK	AQUA / AROMA SYSTEM maintenance
TEST MODE OFF ▶FILL MODE — AIR EXTRACTION ±	Ventilate after fitting or exchanging a canister Test mode: Function test after ventilation Off: For the customer service Filling mode: For the customer service
050 OUTPUT VOLUME ±	Flow rate control (AQUA SYSTEM pump); Values in %
ACTIVATED ROOM SCENT ±	Activation/deactivation of cubicle/cabin fragrancing
Menu 09 SENSOR / UV PROGRAM	
SENSOR AND UV-PROGRAM ◄ ► OK	Select the operating mode and additional settings for Sun Angel devices
AUTO+STANDARD STANDARD ▶AUTOMATIC SENSOR MODE ±	Operating mode preselection: When set to automatic only automatic mode is possible
20 MINUTEN AUTOMATIC TIME ±	Tanning time in automatic mode
180 SECONDS AUTOMATIC ACTIVE TIME ±	Effect in automatic mode: Time following the successful measurement after which the tanning device automatically starts. Actual value = preset value x 2
STYLING SUNSHINE ESSENTIAL SUNSHINE ▶NO PRE-SELECTION PROGRAM SELECTION ±	Preselection of the default tanning programme.

Default setting	Description
Menu 10 OPERATION	
◄ OPERATION ► OK	Various settings for operating the device
⌂OK ◄► ACTIVATED DOOR CONTACT CABIN ±	Message if cubicle door is not closed. When 'Activated': The door contact activates the cabin fragrancing (for devices with the AQUA system) and also generates the start tanning enable signal.
⌂OK ◄► ACTIVATED CLEANING RECEIPT ±	Activated: Cleaning must be acknowledged.
⌂OK ◄► **30** MINUTES MAXIMUM TANNING TIME ±	The device switches off if 30 minutes are exceeded (emergency off).
⌂OK ◄► ⊞ ACTIVATE RESET	Reset the device to the factory defaults.
	⌂OK ◄► TANNING BED RESET RESET
Menu 11 SOUND	
◄ SOUND ► OK	
⌂OK ◄► ACTIVATED VOICE GUIDE ±	Activating / deactivating the Voice Guide
⌂OK ◄► SALON CHANNELS AUX SD-CARD BCD DEZIMAL PULS MUSIC SOURCES ±	Selection of the audio source
⌂OK ◄► MUSIC OFF AUX SD-CARD SALON MUSIC START TRACK **04** STANDBY SOURCE ±	Define the standard audio source in Standby mode

Default setting	Description
⌂OK ◄► MUSIC OFF | AUX | SD-CARD | SALON MUSIC | START TRACK ☐ ☐ ☐ ☒ **04** ▲ START SOURCE ±	Define the standard audio source at start
⌂OK ◄► MUSIC OFF | VOICE GUIDE | SALON MUSIC | AUX | SD-CARD ☐ ☐ ☐ ☐ ☒ ▲ SOURCE DIRECT SELECT ±	Enables direct source selection
⌂OK ◄► MAX. VOLUME | TANNING BED ON | TANNING BED OFF | HEAD-PHONES **060** | **060** | **060** | **060** ▲ VOLUME PERCENT ±	Audio system volume at start (in %)
⌂OK ◄► ⊞ **ACTIVATE** BASIC SETTING ±	Maximum volume setting
⌂OK ◄► **050** BASS RANGE ±	Bass setting
⌂OK ◄► **050** TREBLE RANGE ±	Treble setting
⌂OK ◄► **16** NUMBER OF CHANNELS±	Number of available studio channels
⌂OK ◄► **ACTIVATED** RANDOM GENERATOR ±	SD card only If activated: Tanning start activates the random generator for selecting the music tracks
⌂OK ◄► **2** AUTO VOLUME ±	Basic volume for automatic volume control
⌂OK ◄► ✳((•)) ► ✓ ✗ BLUETOOTH ±	Activate, deactivate the Bluetooth® function permanently. If activated: The Bluetooth® symbol is displayed in standby. ✳ WELCOME

Default setting	Description
⌂OK ◀▶ TAG→✶ BLUETOOTH ±	Change the Bluetooth Connect Pairing name. The number and name can be adapted. Standard: 01 Ergoline

---

Prestige- and Inspiration serie:
Menu 12 DATA TRANSFER

◀ DATA TRANSFER ▶ OK	Select when data shall be transferred to and from the service card (PROFESSIONAL SET - UP CARD, LED LIGHT SHOW & ECO TECH ENERGY SAVING).
⌂OK ◀▶ DATA REQUEST PLEASE WAIT NFC-TRANSMITTER ACTIVE	Message displayed temporarily: information. Message displayed constantly: Please call Service.
⌂OK ◀▶ TRANSFER LED LIGHT SHOW NFC-TRANSMITTER ACTIVE	Message during transfer (example).
DATA TRANSFERRED	There is a message when the data have been transferred successfully.
WRONG CARD	Message when a wrong card is used or when a card with a differing studio identification is used.

3   Index